


## EXB-SLAB SLAB BUCKET






The rock slab bucket expertly gets under layers of rock to break and remove chunks and slabs of rock. The half arrow tip and smooth edge makes it easy to slip between layers of rock to pry and lift slabs.







Hartland Office 96 McLean Avenue Hartland, NB

E7P 2K5 Canada

Ph: (506) 375-4493

**Cambridge Office** 315 Thompson Drive

315 Thompson Drive Cambridge, ON N1T 2B3 Canada

Ph: (519) 623-9500

Blackfalds Office

88 27323 TWP Rd 394 Lacombe County, AB T4M 0S1 Canada

Ph: (403) 356-0048

Lawrenceburg Office 408 Commerce Way

408 Commerce Way Ethridge, TN 38456 USA

Ph: 1 (800) 867-1006

